



**[www.independantplastics.com](http://www.independantplastics.com)**

## **Marine Trailer Bunk Glide Installation Instructions**

1. Please read all of the instructions prior to installing your bunk glides.
2. Pre-plan your bunk glide pattern onto your boat trailer, this will avoid unnecessary cutting.
3. Always remember to wear proper eye protection when cutting your bunk glides.
4. If necessary, cut your bunk glides with a fine-toothed hand saw, or a power skill saw.
5. You will require 2 stainless steel #8 screws  $\frac{3}{4}$ " long with a counter-sunk head, for every 15" piece of bunk glide.
6. No need to pre-drill holes.
7. Do not use a power screw driver; screws should be hand-tightened only.
8. When fastening your bunk glides to your boat trailer, tighten screw fully by hand and then back off screw one-half turn. This will allow for the expansion and the contraction of your bunk glide material, due to weather temperature changes.

Thank you for purchasing your Bunk Glides from Independent Plastics.