



www.independantplastics.com

Ski Guide Installation Instructions

- 1. Please read all of the instructions prior to installing your ski guides.*
- 2. Pre-plan your ski guide pattern onto your trailer, this will avoid unnecessary cutting.*
- 3. Always remember to wear proper eye protection when cutting your ski guides.*
- 4. Cut your ski guides with a fine-toothed hand saw, or a power skill saw.*
- 5 You will require one ¾" long screw for every foot of your ski guide.*
- 6. Type of screw will depend on whether you have a metal or wood bed on your trailer.*
- 7. Pre-drill holes into your ski guides, 1/16th" larger than the screw diameter.*
- 8. When fastening your ski guides to your trailer, tighten screw fully by hand and then back off screw one-half turn. (This will allow for the expansion and the contraction of your ski guide material, due to weather temperature changes)*
- 9. Two screws should be used at the end of each piece of your ski guides.*

Thank you for purchasing your ski guides from Independant Plastics.